CH08 Installation Guide

Abductor And Adductor

Table of contents

Introduction ---------- 1

Assembly ---------- 3

Functional area accessories list ---------- 10

1/10

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts. Lil there are parts missing or damaged during transportation, please call our after-sales service immediately for instructions. Please install the equipment correctly according to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Rubber rod

Level

Hexagon wrench

Two people

Cooling pliers

Adjustable wrench

2/10

Assembly

Step 1: Connect the functional main frame (M1), main connecting frame (M2) and counterweight frame (M3) as shown in the figure.
4X16X40 hexagon screw(flat circle) (M)
4X16X3 spring washer (M)
4 X 16 flat washers (M)
1 X10 Lock Nut(nylon) (M-Sm1)

Step 2: Assemble the two flat seat foam pads (M4) with the functional main frame (M1), and the two counterweight frame foot pads (M5) with the counterweight frame (M3). Connect as shown.



3/10

Assembly

Step 3: Assemble the backrest seat (M6), backrest cushion (M12), headrest (M13) and backrest frame (M11).
Connect the backrest frame (M11) to the functional main frame (M1).
4 X 16 M5 hexagon screw(flat circle) (M)
4*16mm Screw(nylon set Bolt) (M)
Step 4: Connect the backrest seat assembly (M6) assembled in the previous step to the functional main frame (M1).
4X16X40 hexagon screw(flat circle) (M)
4X16X3 spring washer (M)
4*16mm Screw(nylon set Bolt)



4/10

Assembly

Step 5: Put the following method to replace the adjustment handle support plate (M15), the adjustment handle left support plate (M16), the adjustment handle (M17), and the torsion spring (M18) are connected to the adjustment handle support plate (M15), and then connected to the functional main frame (M1).
4 X16X40 hexagon screw(flat circle) (M)
4 X16X3 spring washer (M)



5/10

Assembly

Step 6: Connect the arm support reinforcement frame (M20) to the functional main frame (M1) using the following method:

4 X16X40 hexagon screw(flat circle) (M)
4 X 16 spring washer (M)
4 X 16 M5 Nylon(nut set Bolt)



6/10

Assembly

Step 7: Connect the left and right arm frames (M20) and (M21) to the functional main frame (M1) using the following method:
4X16X40 hexagon screw(flat circle) (M)
4X16X3 spring washer (M)

Step 8: Put the following method to install the 120 cord (not assembly) (M31) and the cord shaft (M32) to the left and right arm brackets (M20) and (M21)

7/10

Assembly

Step 9: Attach the left and right arm rests (M40), (M41) and flange covers (M42) to the left and right frame arms (M20) using the following method:

(M40) (Square):
4 -16 x Hexagon socket head screws (M4210) (M42)

Step 10: Connect the pulley set (M30) to the left and right arm brackets (M20) and (M21) in the following manner:
4 x M5 Hexagon socket head screws (M5)
4 x M5 Nylon locknuts (M50)
4 x 20 M5 flat washers (M52)



8/10

Assembly

Step 11: Connect the two guide rods (M22) and place them into the counterweight frame (M3) using the following method:
Install the counterweight (the counterweight plate (M23) and (M24) with the lowest thirty-ho
Install the guide block assembly (M25) onto the guide rod (M22).
Install the guide rod assembly onto the functional frame (M1).
Install the two nylon plugs (M26) into the guide rod (M22).
Connect the guide rod assembly (M22) to the functional frame (M1) as follows:
2 -16M5 hexagon socket head screws (M5)
Tighten the screws with a hexagon wrench according to the next step.



9/10

Assembly

Step 12: Insert the plug rope 1 (M60) and plug rope 2 (M61) as shown in the figure. The pre-installed rod has needs to be inserted and then installed and
Insert the plug rope 1 (M60) into the left frame and (M20) first, and then connect the other end to the right frame and (M21).
Insert the plug rope 2 (M61) into the left frame and (M20) first, and then connect the other end to the right frame and (M21).

10/10

Assembly

Step 13: Slide the two nylon sliders (M28) into the two headrs (M10) and attach to the counterweight frame (M3) using the header hold-down plate.
Slide the side plates (M29) into the two buffers (M30) and attach to the counterweight frame (M3) using the buffer hold-down.
4 -16M5 hexagon socket head screws (M5)
4 -16M5 flange nuts (M51)

Step 14: Connect the weight rod (M33) to the counterweight frame (M3) and drop the upper plastic cover (M35) into place using the following method:
2 -16M5 hexagon socket head screws (M5)



11/10

Assembly

Important Tips
The Fast Fix (CH10) is assembled, you need to take a general to make sure your seat is fast and safe. The Fast Fix (CH10) is assembled, you need to take a general to make sure your seat is fast and safe. The screws made of the frame hardware and assemblies are tighten the bolts.

12/10

Accessories List

Serial number	Name and specifications	quantity
1	Functional(right side	1
2	Functional main frame	1
3	Main connecting frame	1
4	Foot rest foot pad	2
5	Weight rack foot pads	2
6	Lower pouch	1
7	Hexagon socket head screw (M5*45)	4
8	Hexagon socket head screw (M5*60)	10
9	Spring washer (M5)	10
10	Flat washer (M5*10)	10
11	Screw decorative cap	10
12	Seat pad	1
13	Back cushion	1
14	Universal seat	1
15	Backrest	1
16	Hexagon socket head screw (M5*40)	4
17	Spring washer (M5)	4
18	Nylon plug	2
19	Hexagon socket head screw (M5*60)	2
20	Hexagon socket countersunk screw (M5*60)	4
21	Headrest cover	2

13/10

Accessories List

Serial number	Name and specifications	quantity
22	Torsion Spring	1
23	Hexagon socket head screw (M5*10)	1
24	Torsion spring sleeve	1
25	Adjustable handle support	1
26	Adjust the left support plate of the handle	1
27	Adjustable handle	1
28	Arm support reinforcement frame	1
29	Left frame arm	1
30	Right frame arm	1
31	120 cord (not assembly)	4
32	Cord (3)	4
33	Hexagon socket head screw M5X25	2
34	Pulley	4
35	Right standing rest	1
36	Left standing rest	1
37	Hexagon socket head screw (M5*25)	4
38	Spring washer (M5)	4
39	Nut washer (M5*10)	4
40	Slide pads	2
41	Counterweight	10
42	Guide block set	1
43	Guide rod fixing plate	1
44	Counterweight block	1

14/10

Accessories List

Serial number	Name and specifications	quantity
45	Guide rod	2
46	Hexagon socket head screw (M5*20)	2
47	120 bracket (not for assembly)	1
48	Weight stage 1	1
49	Weight stage 2	1
50	Decorative fitting	1
51	Decorative panels	1
52	Upper pouch	1
53	Upper pouch cover	1
54	Upper cover decorative	1
55	Hexagon socket head screw (M5*30)	2
56	Decal	1