CAIR Installation Guide

Upper / Mid Abdominal Trainer

Catalogs

Brief introduction ---------- 2

assembly ---------- 3

accessory list ---------- 10

1/10

Brief introduction

Please take the time to read these instructions carefully before installation. Please refer to the list in the instruction manual to confirm the completeness and quantity check of all parts. If any parts are missing or damaged in transit, you should call our after-sales service department for assistance. Please keep these instructions. Please refer the instructions to install the equipment correctly.

This equipment is designed to provide the smoothest and most effective workout. After assembly, please inspect all parts before using the equipment to ensure that they are safe. To find out problems during use, you should stop using it immediately to avoid accident injury and equipment damage. And timely reference to the relevant instructions to inquire about the causes, if it can not solve the problem, please contact our after-sales service. After carefully reading the instructions, please maintain

- rubber mallet
- horizontal ruler
- Allen wrench
- Two pointer
- two wrenches
- adjustable wrench

2/10

assemble

Step 1: Attach the Stabilizer(Label 1&2) to the Counterweight Frame (NO.1), as the following Figure (NO.1).

Step 2: Attach the Mid-Abdominal Bracket (NO.) to the Counterweight Bracket (NO.) and the Mid-Abdominal Frame (NO.).

4 * 4 Hexagon socket cheese head screws (M10)
4 * 4 Spring washer (M10) 4 * 4 Flat washer (M10)

Step 3: Attach the Upper-Abdominal Bracket (NO.) to the Mid-Abdominal Connector (NO.) and the Abdominal Frame (NO.), as the following Figure (NO.2).

4 * 4 Hexagon socket cheese head screws (M10)
4 * 4 Spring washer (M10) 4 * 4 Flat washer (M10)

Step 4: Attach the counterweight block (NO.) to counterweight frame (NO.) and counterweight bracket (NO.), as the following Figure (NO.3).

3/10

assemble

Step 5: Attach the Abdominal Press Bar (NO.) and 3D Flywheels(Label 3&4) to the Abdominal Frame (NO.), as the following Figure (NO.4).

4 * 4 Hexagon socket cheese head screws (M12)
4 * 4 Spring washer (M12)
Tighten the bolts with a wrench before proceeding to the next step

4/10

assemble

Step 6: Attach the Abdominal Press Bar(NO.) and 3D Flywheels(Label 3&4) to the Abdominal Frame (NO.), as the following Figure (NO.5).

4 * 4 Hexagon socket cheese head screws (M12)
4 * 4 Spring washer (M12)
Tighten the bolts with a wrench before proceeding to the next step

5/10

assemble

Step 7:Attach the Abdominal Back Pad (NO.) to the Abdominal Side Frame (NO.) using:

4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8)
4 * 4 Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

6/10

assemble

Step 8:Attach the Abdominal Back Pad (NO.) to the Abdominal Side Frame (NO.) using:

4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8)
4 * 4 Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

7/10

assemble

Step 9: Attach the counter (NO.) to the pin side frame (NO.) with:
4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8) 4 * 4 Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

8/10

assemble

Step 10:Slide the two counterweight block rubber pads (NO.) onto the two guide rods(NO.).

Connect the two counterweight lines (NO.) to the two guide rods (NO.) and place them in the counterweight frame (NO.), as the following Figure.

4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8)
4 * 4 Flat washer (M8)
Tighten the bolts with a wrench before proceeding to the next step

Step 11: Attach the two guide rod assembly to counterweight frame (NO.) with the two connecting rods fixing set.

Attach the guide rod assembly to the pin side frame (NO.).

Attach the guide rod assembly to the counterweight bracket (NO.).

Attach the guide rod assembly to the counterweight bracket (NO.).

Attach the guide rod assembly plate (NO.) to the counterweight bracket (NO.) by:

2 * 2 Hexagon socket cheese head screws (M8)
Tighten the bolts with a wrench before proceeding to the next step

9/10

assemble

Step 12: Attach the two 3D Pin Plate (NO.) to the counterweight bracket (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8) 4 * 4 Flat washer (M8)

Attach the Pin Plate Spacer (NO.) and the 3D Pin Plate (NO.) to the Abdominal Connector (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8) 4 * 4 Flat washer (M8)

Attach the Abdominal Flange (NO.) to the Abdominal Connector Bracket (NO.) using:
4 * 4 Short (NO.) 4 * 4 Hexagonal self-locking nuts (NO.)
4 * 4 Long (NO.) 4 * 4 Hexagonal self-locking nuts (NO.)

Attach the 3D Left Pivot Shaft (NO.) and the 3D Right Pivot Shaft (NO.) to the Abdominal Connector (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)

Attach the Pin Plate Spacer (NO.) and the 3D Pin Plate (NO.) to the Abdominal Connector (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Spring washer (M8) 4 * 4 Flat washer (M8)

Attach the two Pin Plate Spacers (NO.) to the counterweight bracket (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)

10/10

assemble

Step 13:Slide the two Tie Plate (NO.) onto the two Buffer (NO.) and use the Buffer Plate (NO.) to attach the Counterweight Bracket (NO.).

Slide the two Pivot Shaft Set (NO.) onto the two Buffer (NO.) and use the Buffer Plate to attach to the Counterweight Bracket (NO.) using:
4 * 4 Hexagon socket cheese head screws (M8)
4 * 4 Hexagonal self-locking nuts (M8) 4 * 4 Flat washer (M8)
Attach the upper thread bar cover (NO.) to the upper thread (NO.).

Attach the two two cover (NO.) to the counterweight bracket (NO.) using:
4 * 4 Hexagon socket cheese head screws (M5)

11/10

assemble

Important Line

Now that the Upper-Mid Abdominal Trainer is assembled, you need to make a decision on where you want to place it and how you want to use it. Refer to the following figure to see the different positions. If it is not carried out in the correct position, it will affect the use of the machine and cause injury.

12/10

accessory list

NO	Name and specification	QTY
1	Frame	1
2	connection frame	1
3	side frame	1
4	Hexagon socket cheese head screws (M8X51)	12
5	spring washer (D)	12
6	Flat washer (D)	12
7	Connection frame	1
8	counterweight label shield	1
9	Hexagon socket cheese head screws (M8X45)	4
10	counterweight fastener	1
11	counterweight bracket	1
12	Press arm	1
13	Abdominal Flange	1
14	Mechanism cam	1
15	Hexagon socket cheese head screws (M8X60)	4
16	Mechanism cam	1
17	Abdominal Press Bars	1
18	Backrest	1
19	Hexagon socket cheese head screws (M8X50)	4
20	pulley block (D)	4
21	Flat washer (D)	4

13/10

accessory list

NO	Name and specification	QTY
22	Cushion	1
23	Sectional fixedmetallic bolt Bar	1
24	Counterweight rubber pads	2
25	Counterweight line	2
26	Hexagon socket cheese head screws (M8X30)	2
27	Weight block	1
28	guide block set	2
29	guide bar mounting plate	2
30	guide rod	2
31	Backrest	1
32	pivot (D)	1
33	Pivot handle (D)	1
34	Hexagonal self-locking nuts (M10)	2
35	Effector	1
37	roll bar	2
38	shell rubber (D)	2
39	cover frame (FRONT)	1
40	Armpad set (M/L)	1
41	shield	1
42	Counterweight frame Accessories Kits	1

14/10

accessory list

NO	Name and specification	QTY
43	Counterweight frame Accessories Kits	1
44	counterweight upper shroud	1
45	Upper Abdominal Pad Set	1
46	Counterweight cover plug cover	1
47	Hexagon socket cheese head screws (M8X80)	2

Note:The screwdriver parts are not listed in this table.