CG185 Installation Guide

Lower Abdominal Trainer

Table of contents

Introduction ---------- 2

Assembly ---------- 3

List of accessories ---------- Attached

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the accessories and quantity of all parts (if there is any missing part or damage during transportation, please call our after-sales service immediately for instructions). Please install the equipment correctly according to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue.

tool	Rubber rod
	Level
	Hexagon wrench
	Circlip pliers
	Adjustable wrench

Note: It is recommended that two or more people work together during assembly.

Assembly

Step 1: Connect the counterweight lower guard (NO) to the counterweight frame (N1) Fixed with M8*20 screws
(M Hexagon socket head screw ΦM8 NO)

Step 2: Connect the Horizontal Abdominal Muscle Attachment Frame Assembly (M2), Horizontal Abdominal Muscle Side Frame Assembly (M3) and Pet Weight Frame (M1) using the following method.
(ΦHexagon socket head screw Φ10M3 (M)
(ΦFlat washer Φ10 (N)
(Zn Flat washer Φ10 (N)

Step 3: Install the Z Weight rack Part (M4) to the weight rack (M1)
Install the Z Flat steel foot pads (M5) to the horizontal abdominal muscle side frame assembly (M3)



Assembly

Step 4: Connect the leg press stand assembly (M11) to the horizontal abdominal muscle arm assembly (M12) in the following way
* 15 M Hexagon screw (M15) + 15 Hexagon socket countersunk screw ΦM15 (M17)

Step 5: Connect the horizontal abdominal muscle cable rod assembly (M13), the horizontal abdominal muscle arm assembly (M12), and the horizontal abdominal muscle connecting frame assembly (M2) in the following manner
* 15 M Hexagon screw (M15) + 20 Hexagon socket countersunk screws ΦM15 (M17)
15 M Hexagon Cap (M16)

Assembly

Step 6: Install the horizontal abdominal muscle connector assembly (M18) onto the horizontal abdominal muscle side frame assembly (M3) in the following manner:
(ΦHexagon socket head screw Φ10M3 (M)
* 4 Spring Washers Φ8 (M8)
* 4 Flat washers Φ8*20*2 (M10)



Assembly

Step 7: Slide the two rubber weight pads (M20) onto the two guide rods (M18)
Install the guide rod mounting plate (M19) onto the guide rod, fix the guide rod (M18) and place them into the counterweight frame (N1) in the following manner:
(ΦHexagon socket head screw ΦM10 (M22)
(ΦFlat washer Φ10 (N)
(ΦFlat washer Φ20*2 (M21)
Tighten the bolts with a wrench before proceeding to the next step

Step 8: Install the 6 counterweight (M23) onto the two guide rods (M18) with the uneven facing up.
Install the guide block assembly (M24) onto the guide rod (M18).
Install the guide rod mounting plate (M19) onto the guide rod (M18).
Slide the guide bar retaining plate (M25) onto the guide bar (M18).
Install the guide rod mounting plate (M19) to the counterweight frame (N1) as follows:
(ΦHexagon socket head screw ΦM10 (M22)
Tighten the bolts with a wrench before proceeding to the next step



Assembly

Step 9: Insert the wire rope (M26) as shown in the figure. The pre-installed wire wheel needs to be removed and then reinstalled.
Note that these cords are installed synchronously with the wire rope (M26)

Step 10: Connect one end of the wire rope (M26) to the winding drum (M22) and the other end to the counterweight frame (N1).

Assembly

Step 11: Slide the two trim strips (M31) into the two fenders (M30) and attach to the counterweight frame (N1) using the fender bolt‑down plates.
Slide the trim plate (M32) into the two baffles (M30) and attach to the counterweight frame (N1) using the fender bolt‑down plates.
Attach the upper guard (M33) to the counterweight frame (N1) as follows:
(ΦHexagon socket head screw ΦM10 (M7)

Step 12: Attach the upper trim trim (M34) to the counterweight frame (N1) using the following method:
(ΦHexagon socket head screw ΦM8 (M36)

Step 13: Snap the upper shield cover (M35) onto the upper shield (M34)

Assembly

Important Tips

Now that the lower abdominal trainer is assembled, you need to take a moment to make sure your unit is level and plumb. Use a level to check that the guide bars are plumb in both directions. If they are not plumb, you may have to loosen some of the floor hardware and reassemble and tighten the bolts.

Accessories List

Serial number	Name and specifications	quantity
1	Counterweight rack	1
2	Horizontal abdominal muscle connection frame assembly	1
3	Horizontal Abdominal Muscle Side Rack Assembly	1
4	Weighted foot pads	2
5	Flat seat foot pad	2
6	Counterweight lower guard	1
7	Hexagon socket head screw ΦM10	8
8	Hexagon socket head screw ΦM8*20	14
9	Spring washer 10M	16
10	Flat washer 10D	16
12	Horizontal abdominal muscle arm assembly	1
13	Horizontal Abdominal Muscle Winding Rod Assembly	1
14	leg press stand assembly	1
15	M aluminum cover	2
16	M aluminum cover	1
17	Hexagon socket countersunk screw ΦM10D	1
18	Horizontal abdominal muscle armrest assembly	1
19	Silvered weight guide rod	2
20	Counterweight rubber pad	2
21	Counterweight rack base	2

Accessories List

Serial number	Name and specifications	quantity
22	Hexagon socket head screw ΦM20	4
23	Spring washer 20	2
24	Flat washers 20	2
25	Counterweight	14
26	Guide block set	1
27	Guide rod fixing plate	1
28	Counterweight lock	1
29	Wire Rope	1
30	Bend	4
31	Counterweight decorative strip	2
32	Counterweight centre decorative plate	1
33	Counterweight upper guard	1
34	Upper cover decoration	1
35	Upper guard cover	1
36	Hexagon socket head screw ΦM30	4

Note: Pre-assembled parts are not listed in this table.