

Catalog

Brief introduction ——————————————— 2
Assemble ——————————————— 3
Accessory list ——————————————— 13

1/13

Brief

Please take the time to read these instructions carefully before installation. Please refer to the list in the instruction manual to confirm the completeness and quantity check of all the. If any parts are missing or damaged in transit, we should call our after-sales service immediately! When installing the equipment, please follow the instructions to install the equipment correctly.

This equipment is designed to provide the smoothest and most effective workout. After installation, you need to understand all the functions in order to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. And timely reference to the relevant instructions to inquire about the cause, if you can not solve the problem, please call our after-sales service. After carefully reading all the instructions, please continue

rubber mallet
horizontal ruler
Allen wrench
Two person
spring clamp
adjustable wrench

2/13

Assemble

Step 1:Attach a Rectangular Foot Pad (M2) to the Foot Plate of the Hip Trainer Base Frame Assembly (M1).

Step 2:Attach the Foot Pedal (M3) to the Bottom Frame Assembly (M1) of the Glute Trainer using the following method:

• 4 ⊙ M10*M20Hexagon socket cheese head screws (M23)
• 4 ⊙M10Flat washer (M24)
• 4 ⊙M10Flat washer (M7)



3/13

Assemble

Step 3: Attach a Rectangular Foot Pad (M2) to the Hip Trainer Side Frame Assembly (M6).

Step 4:Attach the Hip Trainer Bottom Frame Assembly (M1) to the Hip Trainer Side Frame Assembly (M6) using the following method:

• 12 ⊙M10*60Hexagon socket cheese head screws (M23)
• 8 ⊙M10Hexagon socket cheese head screws (M8)
• 20 ⊙M10Flat washer (M24)
• 8 ⊙M10Flat washer (M7)

4/13

Assemble

Step 5: Attach the 2 Counterweight Rack Foot Pads (M22) to the foot plates of the Counterweight Rack (M20).

Step 6:Attach the Counterweight Rack Lower Shroud (M21) to the Counterweight Rack (M20) using the following method:

• 12 ⊙M10Hexagon socket cheese head screws (M23)

Step 7: Slide the 5 kg Counterweight Block (M25), Weighted Frame (M18), and Attachment Frame (M19) onto the Counterweight Rack (M20).

• 6 ⊙M10M20Hexagon socket cheese head screws (M23)
• 6 ⊙M10Flat washer (M7)
• 2 ⊙M10Nut (M9)
• 2 ⊙M10M20Hexagon socket cheese head screws (M23)



5/13

Assemble

Step 8:Slide the two Counterweight Rack Guide Rods (M17) onto the two Glute Rack (M16).

Connect the two counterweight bases (M16) to the two guide rods (M16) and place them in the counterweight (M20) as follows:

• 2 ⊙ M*20 Hexagon socket cheese head screws (M23)
• 2 ⊙M10Flat washer (M24)
• 2 ⊙M10Nut (Lid washer M12)

Tighten the bolts with a wrench before proceeding to the next step.

Step 9: Attach the Counterweight Blocks (M25) to the Guide Rods (M16) with the isolation tube facing in.

Install the guide block set (M22) onto the guide bar (M16).

Insert the counterweight block pin (M25) into the counterweight block (M22).

Slide the guide bar retainer plate (M24) onto the guide bar (M16).

Attach the guide bar mounting plate (M23) to the counterweight bracket (M18) by.

• 2 ⊙ M*25 Hexagon socket cheese head screws (M23)

Tighten the bolts with a wrench before proceeding to the next step

6/13

Assemble

Step 10: Thread the wire rope (M26) as shown in the picture, the pre-installed sleeves need to be disassembled and reassembled.

Note that these sleeves are installed in synchronization with the wire rope (M26).

Step 11:Connect one end of the wire rope (M26) to the Seat Frame (M1) and the other end to the counterweight frame (M18).

7/13

assemble

Step 12:Slide the two Trim Strips (M8) onto the two Baffles (M27) and use the Baffle Plates to attach to the Counterweight Rack (M18).

Slide the Top Cover (M28) onto the two Baffles (M27) and use the Baffle Plates to attach to the Counterweight Rack (M18).

Attach the upper shroud (M30) to the counterweight frame (M18) by.

• 4 ⊙ M*20Hexagon socket cheese head screws (M23)

Step 13: Attach the Top-Cover Trim (M31) to the Counterweight Frame (M18) by.

• 6 ⊙ M*20Hexagon socket cheese head screws (M23)

Step 14: Snap Upper Shroud Top Cover (M32) to Upper Shroud (M30)

8/13

Assemble

Important tips

Now that the Glutaeus Maximus Trainer is assembled, you need to take a few minutes to check and tighten all the bolts. Make sure that the bolts and the guide rods are vertical in both directions. If it is not vertical you must loosen some of the frame hardware to reassemble and tighten the bolts.

9/13

Accessory List

NO	Name and specification	QTY
1	Hip Trainer Base Assembly	1
2	Rectangular Foot Pad	2
3	Footrest	1
4	Hexagon socket cheese head screws(M10*M20)	4
5	spring washer(M10)	10
7	Flat washer(M10-M20)	12
6	Hip Trainer Side Frame Assembly	1
9	Hexagon socket cheese head screws(M10*140)	1
10	counterweight	1
11	Indicator for counterweight	1
12	counterweight foot	2
13	Hexagon socket cheese head screws(M8*50)	4
14	connection frame	1
15	Counterweight base	2
16	Hexagon socket cheese head screws(M8*50)	20
17	Counterweight rubber pads	2
18	counterweight base	1
19	Hexagon socket cheese head screws(M8*50)	2
20	spring washer(M8)	2
21	flat washer(M8-D40)	2
22	Weight stack	12

10/13

Accessory list

NO	Name and specification	QTY
23	Guide block set	1
24	Guide bar mounting plate	1
25	Counterweight block plate	1
26	Cable	1
27	shield	4
28	decorative strip	2
29	Decorative plate	1
30	Lower Shroud	1
31	Top cover trim	1
32	Upper Shroud Top Cover	1
33	Hexagon socket cheese head screws(M8*60)	4

Note: Pre-assembled parts are not listed in this table.