Catalog

Introduction ---------- 2
assembly ---------- 3
accessory list ---------- 12

1/12

catalogue

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts.If there are parts missing or damaged during transportation, please call our after-sales service department in time for replacement. Please install the equipment correctly according to the relevant instructions.

This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid personal injury and equipment damage. Please refer to the relevant instructions in time to resolve these issues. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue.

rubber mallet
level ruler
allen wrench
Two people
spring clamp
adjustable wrench

2/12

assembly

Step 1: Attach the Counterweight Lever Decal (NO. 1) to the Counterweight Plate (NO.3x).

* 2 x Bumper socket sleeve head screws (NO.1)

Step 2: Connect the Horizontal Frame 2 Seat Connection Frame 1 (NO.4) to the Counterweight Plate (NO.3x) the following way:

* 4 x Bumper socket sleeve head screws (NO.1)
* 4 x Spring washer (NO.7)
* 4 x Flat washer (NO.8)

Step 3: Attach 2 Counterweight Rods (NO.2x) to Counterweight Rack (NO.3x)

3/12

assembly

Step 4: Connect the Horizontal Frame 2 Head Side Frame (NO.5x) to the Connection Frame 2 (NO.4x) the following way:

* 4 x Bumper socket sleeve head screws (NO.1)
* 4 x Spring washer (NO.7)
* 4 x Flat washer (NO.8)

Step 5: Attach the 2 Flat Head Feet (NO.6) to the Horizontal Frame 2 Headed Side Frame (NO.5x).

4/12

assembly

Step 6: Connect the Horizontal Frame 2 Seat Connection Frame 2 (NO.4) to the Connection Frame 1 (NO.4x) and Frame (NO.3x) the following way:

* 4 x Bumper socket sleeve head screws (NO.1)
* 4 x Spring washer (NO.7)
* 4 x Flat washer (NO.8)
* 4 x Bumper socket sleeve head screws (NO.1)

5/12

assembly

Step 7: Attach the Horizontal Frame 2 Head Side Cushion (NO.5) to the Attachment Frame 12 (NO.5) and Side Frame (NO.5x).

* 4 x Bumper socket sleeve head screws (NO.1)

Step 8: Connect the 2 Back Plug (NO.) to the Horizontal Frame 2 Head Side Frame (NO.5x). Connect the Horizontal Frame (NO.) to the Horizontal Frame 2 Connection Frame 12 (NO.).

6/12

assembly

Step 10: Connect the Horizontal Frame 2 Seat Cushion (NO.) to the Horizontal Frame 2 Connection Frame 12 (NO.) as follows:

* 4 x Bumper socket sleeve head screws (NO.1)
* 4 x Spring washer (NO.7)
* 4 x Flat washer (NO.8)

Tighten the bolts with a wrench before proceeding to the next step.

Step 11: Attach the 12 Counterweight Blocks (NO.) to the Guide Rods (NO.2) with the Counterweight Rack (NO.3x).

Install the guide block set (NO.) onto the guide bar (NO.).

Install the guide block set (NO.) onto the guide bar (NO.).

Slide the guide bar retainer plate (NO.) onto the guide bar (NO.).

Slide the guide bar retainer plate (NO.) onto the guide bar (NO.).

* 2 x Bumper socket sleeve head screws (NO.1)

Tighten the bolts with a wrench before proceeding to the next step.

7/12

assembly

Step 12: Slide the two counterweight block rubber pads (NO.) onto the two Counterweight Rods (NO.2x).

Connect the two counterweight lower (NO.) to the two guide rods (NO.) and allow them to rest on the Counterweight Rack (NO.3x).

* 4 x Bumper socket sleeve head screws (NO.)
* 4 x Spring washer (NO.)
* 4 x Flat washer (NO.)

Tighten the bolts with a wrench before proceeding to the next step.

8/12

assembly

Step 13: Connect the Horizontal Frame2 Set Iron (NO.) and Flange (NO.) to the Horizontal Frame2 Set Connector 2 (NO.) as follows:

* 4 x Bumper socket sleeve head screws (NO.)
* 4 x Spring washer (NO.)
* 4 x Mechanism cap (NO.)

9/12

assembly

Step 14: Attach the 2 Seat Plug (NO.) to the Horizontal Frame2 Seat Connector Frame 2 (NO.).

* 4 x Bumper socket sleeve head screws (NO.)
* 4 x Mechanism cap (NO.)

10/12

assembly

Step 15: Connect the Horizontal Frame2 Set Iron (NO.) and Flange (NO.) to the Horizontal Frame2 Set Connector 1 (NO.) as follows:

* 4 x Bumper socket sleeve head screws (NO.)
* 4 x Spring washer (NO.)
* 4 x Mechanism cap (NO.)

11/12

assembly

Step 16:Connect the pre-installed M8 and 10# stick absorber First, thread in the wire rope (NO.) as shown in the diagram and then re-install all the sheaves.

Connect the 10# wire sheave (NO.) and 2 wire sheet bases (NO.) to the horizontal stand 2 (NO.) as shown in the diagram.

* 4 x Bumper socket sleeve head screws (NO.)
* 4 x Spring washer (NO.)

Step 17:Thread one end of the wire rope (NO.) first to the Flange (NO.) and then the other end into the counterweight frame (NO.).

12/12

assembly

Step 18:Slide the two Seat Slide (NO.) onto the two Buffer (NO.) and use the Buffer Plates to attach to the Counterweight Rack (NO.).

Slide the Slim Plate (NO.) onto the two Buffer (NO.) and use the Buffer Plates to attach to the Counterweight Rack (NO.).

Attach the spare shroud (NO.) to the counterweight frame (NO.3x).

* 4 x Bumper socket sleeve head screws (NO.)

Step 19: Snap the upper shroud top cover (NO.) to the upper shroud (NO).

13/13

assembly

Important Tips

Now that the Prone Leg Curl is assembled, you can proceed to take a moment to clean and wipe down all tools and cloths. Now is time to check that the unit is level and that all bolts are tightened. Please read the following user manual one of the final footsteps to reasonable and tighten the bolts.

13/13

accessory list

NO	Name and specification	QTY
1	weight frame	1
2	Counterweight bracket 2	1
3	Bumper socket sleeve head screws (M20*65)	10
4	Spring washer (10)	10
5	Flat washer (10)	10
6	counterweight lower shield	1
7	Bumper socket sleeve head screws (M*65)	4
8	counterweight faircord	1
9	side cover	2
10	Flat silicon fairmats	2
11	Connecting bracket2	2
12	Bumper socket sleeve head screws (M20*65)	2
13	Seat fairmats	1
14	Bumper socket sleeve head screws (M20*65)	2
15	Back plug	2
16	Press arm	1
17	Foamex	1
18	Bumper socket countersunk head screws (M20*65)	2
19	8# mechanism cap	2
20	7#mechanism cap	2
21	leg press stand	1

accessory list

NO	Name and specification	QTY
22	Universal Counterweight Guide Bar	2
23	Counterweight connection panel	2
24	Counterweight Frame base	2
25	Bumper socket sleeve head screws (M8*20)	2
26	Spring washer 8#	2
27	Flat washer 8#	2
28	height stick	10
29	Buffer	2
30	Buffer Pad Fitting plate	1
31	height stick pad	1
32	cable	1
33	Idlerfix	1
34	pad bar	2
35	Wire Rope(Buy Building)	2
36	Lower	1
37	shroud	1
38	Counterweight Inserse Reinforcing Strip	2
39	Counterweight Inserse Reinforcing plate	1
40	Counterweight upper shroud	1
41	Top cover decorations	1
42	Upper Shroud Top Cover	1
43	Bumper socket sleeve head screws (M8*65)	4

Note:The accessories and parts are not listed in this table