CS815 Installation Guide
Converging Independent 1st Pull Down



Table of contents

Introduction ---------- 2

Assembly ---------- 3

Accessories List ---------- 12

1/12

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts

If there are parts missing or damaged during transportation, please call our after-sales service immediately for instructions. Please install the equipment correctly according

to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it

correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in

time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Rubber rod
Level
Hexagon wrench
Two people
Circlip pliers
Adjustable wrench

2/12

Assembly

Step 1: Use the following method to connect the main side frame (M01), universal connecting frame (M02), Connect to the weight rack (M11 and install the weight rack foot pads (M12 and flat seal foot pads (M1
• 7*4L Hexagon socket head screw M10*65 (M03
• 7*4L Flat washer M10 (M04
• 4L Flat washer M8 (M13
• 4L Spring washer M8 (M14

Step 2: Connect the counterweight lower guard (M15 to the counterweight frame (M11 using the following
• 2)Hexagon socket head screw M5*40 (M16



3/12

Assembly

Step 3: Connect the left and right lower arms (M19 (M18 and the 7A stainless cover (M17) to the main side frame (M01 using the following method:
• 4)Hexagon socket countersunk screw M10X25 (M20

Step 4: Connect the handlebar (M22 to the left and right lower arms (M19 (M18 in the following manner:
• 2L Hexagon socket head screw M10*65 (M03
• 2L Flat washer M10 (M04
• 2L Threaded decorative sleeve (M23

4/12

Assembly

Step 5: Attach the seat cushion (M29 to the universal seat frame (M30 using the following method:
• 4L Hexagon socket head screw M8*65 (M31
• 4L Spring washer M8 (M32
• 4L Flat washer M8 (M33



5/12

Assembly

Step 6: Connect the Universal Seat (M30 to the Main Side Frame (M01 using the following method:
• 4L Hexagon socket head screw M10*65 (M03
• 4L Spring washer M10 (M04
• 2L Threaded decorative sleeve (M23

Step 7: Connect the leg press assembly (M24), handle bar (M22 and main side frame (M01 using the following method:
• 4L Hexagon socket head screw M10*65 (M03
• 4L Spring washer M10 (M04
• 4L Threaded decorative sleeve (M23



6/12

Assembly

Step 8: Install the 18 counterweights (M42) onto the guide rods (M39 with the spacers facing up. Install the guide block assembly (M40 onto the guide rod (M39.
Insert the counterweight pin (M43 into the counterweight (M42).
Install the counterweight cover plate (M41 onto the guide rod (M39.
Install the guide rod mounting plate (M37) to the counterweight frame (M11 as follow:
• 4)Hexagon socket head screw M8*20 (M38
Tighten the bolts with a wrench before proceeding to the next step



7/12

Assembly

Step 9: First disassemble the pre-installed(CS8 wire sheet (M35), Insert the wire rope 1 (M36) as shown in the figure, and Install it to the main side frame (M01. Note that these cords are installed simultaneously with the wire rope.

Step 10: Connect one end of the wire rope 2 (M34) to the counterweight frame (M11 and the other end to the CS8 wire sheet bracket (M34), are connected.



8/12

Assembly

Step 11: Slide the two wire strips (M26) into the two fenders (M25) and attach to the counterweight frame (M11 using the fender hold-down plates.
Step 12: Attach the pulley assembly (M27) to the counterweight frame (M11 using the counterweight frame (M11 using the baffle prevent plate.
Attach the upper guard (M45) to the counterweight frame (M11 as follows:
• 4)M5*12 Hexagon socket head screws (M47

Step 13: Attach the upper cover trim (M46) to the counterweight frame (M11 in the following manner.
4)M4*20 Hexagon socket head screws (M48



9/12

Assembly



Important Tips
use that tot cover is assembled, be sure to use a magnet to make sure your belt is level and plumb. Use a level to check that the guide bars are plumb in both directions. Use a plumb bob to make sure bars to locate some of the frame hardware and reassemble and tighten the bolts.

10/12

Accessories List

Serial number	Name and specifications	quantity
1	Counterweight rack	1
2	Hexagon socket head screw (M3*6(45	6
3	Counterweight lower guard	1
4	Weight rack foot pads	2
5	Flat seal foot pad	2
6	Main side frame	1
7	Strengthen the connecting frame	1
8	Universal connecting frame	1
9	Hexagon socket head screw (M10*25	20
10	Spring washer (10	24
11	Flat washer (10	16
12	Threaded decorative sleeve	16
13	Left armrest axe	1
14	Right armrest axle	1
15	Handle	2
16	Hexagon socket countersunk screw M10X25	4
17	7A stainless cover	2
18	Hexagon socket head screw M10x35	2
19	Universal seat frame	1
20	Leather	1
21	Hexagon socket head screw (M8*20	4

11/12

Accessories List

Serial number	Name and specifications	quantity
22	Spring washers (8	4
23	Flat washers (8	4
24	Leg press assembly	1
25	Fenderbar	2
26	Hexagon socket countersunk screw M10X70	2
27	Guide rod fixing plate	1
28	Hexagon socket head screw (M4*20	2
29	Universal weight guide rod	2
30	Guide block set	1
31	Counterweight	18
32	Counterweight latch	1
33	CS8 cord box	4
34	CS8 wire cord bracket	1
35	Wire Rope 1	1
36	Wire Rope 2	1
37	Guard	4
38	Counterweight decorative strip	2
39	Counterweight source decorative plate	1
40	Counterweight upper guard	1
41	Upper guard cover	2
42	Upper cover decoration	1
43	Hexagon socket head screw (M4*40	4

Pre-assembled parts are not listed in this table.

12/12