C6D08 Installation Guide
Leg Extension / Lying Leg Curl

catalog

Brief introduction ---------- 2
assembly ---------- 3
accessory list ---------- attach

1/12

Brief introduction

Please take the time to read this instruction carefully before installation. Please refer to the exploded view for the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please contact our after-sales service immediately for instructions). Please install the equipment correctly according to the following instructions.
This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. If you have any questions, please contact us. We will answer for the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Tool	rubber mallet
	level ruler
	Hexagon wrench
	Circlip pliers
Adjustable wrench	
Note: When assembling, two or more persons are recommended to operate.	

2/12

Assemble

Step 1:Bolt together components #1, #4, and #8 using the following method, which requires the lower channel (#2) to be installed first.
- 5/16inch washer #20 (#3) and nylock screw M5#25 (#6)
- 3/8inch washer #10 (#5)
- 3/8flat washers #10 (#9) (#10)
- 3/8nylock screw channel head screw M10#30 (#11)
- 3/8hexagon socket cheese head screw M10#4 (#2)

Step 2: Attach 2 Counterweight Post (#6) to Counterweight Rack (#1)
Step 3: Attach 2 Flat Pad Post (#7) to Main Frame (#8)

3/12

Assemble

Step 4:Attach the Cushion Assembly (#12), and Handle Assembly (#13) using the following method.
- 5/16hexagon socket cheese head screws M5#25 (#12)
- 3/8 Spring washers #8 (#13)
- 3/8 Flat washers #8 (#14) (#15)

4/12

Assemble

Step 5:Bolt the cushion assembly (#12), backrest assembly (#17), Linkage-1 (#18), and Backrest Linkage-2 (#19) together.(Linkage support plate-2 (#20), and Linkage-3 (#21) will then correspond according to the diagram using the following method.
- 5/16hexagon socket cheese head screws M10#25 (#8)
- 3/8spring washer #10 (#9)
- 3/8nylock washer #10 (#10) (#20)

5/12

Assemble

Step 6:Connect the Extend Flat Leg Force Arm (#22), and the Extend Flat Leg Main Frame (#8) in the following way.
- 5/8hexagon socket cheese head screws M16#25 (#8)
- 5/8 Spring washers #16 (#9)
- 5/8nut washer #16 (#10) (#24)

6/12

Assemble

Step 7: Slide the two Counterweight Block Rubber Pads (#29) onto the two Guide Bars (#23).

Connect the two counterweight bars (#26) to the two guide rods (#23) and place them in the Counterweight Blocks (#27) in order.
- 2 x Hexagon socket cheese head screws M10#25 (#28)
- 2 x Spring washer M10 (#29)
- 2 x flat washer M10 (#30) (#31)

Tighten the bolts with a wrench before proceeding to the next step

Step 8: Attach the 18 Counterweight Blocks (#27) to the Guide Rods (#23) with the isolation blocks (#32).
Install the guide block set (#28) onto the guide bar (#23).

Insert the counterweight block pin (#28) into the counterweight block (#27).

Slide the guide bar retainer plate (#25) onto the guide bar (#23).
Attach the guide bar mounting plate (#24) to the counterweight frame (#1) by,
- 2 x Hexagon socket cheese head screws M10#25 (#24)

Tighten the bolts with a wrench before proceeding to the next step

7/12

Assemble

Step 9:Split the wiring on each component, then connect it with wire rope (#41) and individual wire sheets as shown below.

Finally recover the wire sheet in the same position as it was before the split.

8/12

Assemble

Step 9:Slide the tan trim strips (#26) into the tan baffles (#41) and use the baffle plates to attach to the counterweight rack (#1).

Slide the Tan Plate (#42) into the baffles (#41) and use the Baffle Plates to attach to the Counterweight Frame (#1).
Attach the upper shroud (#34) to the counterweight frame (#1) by,
- 4 x Hexagon socket cheese head screws (#4)

Step 10: Attach the Tan Cover Trim (#36) to the Counterweight Frame (#1) by,
- 4 x Hexagon socket cheese head screws (#4)

Step 11: Snap Upper Shroud Top Cover (#33) to Upper Shroud (#34)

9/12

Assemble

Important Tip:
At this point the C6D08 has been assembled, so you will need to take a moment to make sure your unit is level and plumb. See the next page for a diagram of the completed assembly.

10/12

Accessory list

NO	Name and specification	QTY
1	counterweight frame	1
2	counterweight lower shield	1
3	Hexagon socket cheese head screws (M5#30)	6
4	Fitting attachment bracket 1	1
5	Low-rolling resistance main frame	1
6	counterweight footrest	2
7	Flat pillow foot mats	2
8	Hexagon socket cheese head screws M10#25	24
9	spring washer M10	26
10	flat washer M10 (#20)	28
11	Hexagon socket cheese head screws M10#30	2
12	handle	2
13	Cushion assembly	1
14	Hexagon socket cheese head screws M5#25	4
15	spring washer M5	4
16	flat washer M5-S16	8
17	backrest cushion	1
18	Linkage-1 assembly	1
19	Backrest Linkage-2 Assembly	1
20	Backrest Linkage Plate-2	1

11/12

Accessory list

NO	Name and specification	QTY
21	Linkage-2 assembly	1
22	force arm	1
23	Guide bar fitting plate	1
24	Hexagon socket cheese head screws (M8#20)	4
25	guide rods	2
26	Guide block set	1
27	counterweight	18
28	Counterweight block pins	1
29	Counterweight rubber pads	2
30	counterweight base	2
31	baffle	4
32	decorative plate	1
33	decorative strip	2
34	upper shield	1
35	Upper Shroud Top Cover	1
36	Lower shroud trim	2
37	Hexagon socket cheese head screws (M6#30)	4

12/12