Catalog

Brief introduction ---------- 2

Assemble ---------- 3

Accessory List ---------- 10

1/11

brief introduction

Please take the time to read these instructions carefully before installation. Please refer to the List in the instruction manual to confirm the completeness and quantity check of all parts (if any parts are wrong or damaged in transit, please call our after-sales service immediately). When installing the equipment, please follow the relevant instructions to install the equipment correctly.

In order to complete the installation of the equipment safely and most effective workout, After installation, you need to understand all the functions in order to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. And promptly refer to the relevant instructions to inquire about the cause, if you can not solve the problem, please call our after-sales service. After carefully reading all the instructions, please continue

Tool	rubber mallet
	Level ruler
	Allen wrench
	open end clamp
	adjustable wrench

Note: When assembling, two or more persons are recommended to operate

2/11

Assemble

Step 1: Attach 2 Counterweight Rod Rest (WG) to Counterweight Rack (WC) Install 2 Flat s(Qty12) Part (WGS) to main Frame assembly (WC)

Step 2: Attach the Counterweight Lower Shroud (WC) to the Counterweight Frame (WC)

- 2 x Bumpon socket sleeve head screws M3*45 (WC)

Step 3: Connect the Sitting Attachment (WA), the Main Frame Assembly (WC), and the Counterweight Frame (WC) with the 1.5" Pivot Axle (WA)

- 4 x Bumpon socket sleeve head screws M3*45 (WC)
- 2 x Flat washer M10-OD30 (WC)
- 1 x Flat washer M20-OD50 (WC)

3/11

Assemble

Step 4:Attach the 1st Sitting Seat Frame Assembly (WCG) to the Main Frame Assembly (WC) using the following method:

- 4 x Bumpon socket sleeve head screws M3*45 (WC)
- 2 x Flat washer M10-OD30 (WC)
- 4 x Flat washer M20-OD50 (WC)

Step 5:Attach the Pivot Axle Limit Assembly (WCZ) to the Main Frame Assembly (WC) using the following method:

- 2 x Bumpon socket sleeve head screws M3*45 (WC)
- 2 x spring washer M10 (WC)
- 2 x Flat washer M20-OD50 (WC)



4/11

assemble

Step 6: Attach the Oscillating Force Bar Assembly (WCD) and the 2 Pivot Arm Linkage Fixing Plates (WCG), which are pre-installed on the Main Frame Assembly (WC), to the Sitting Seat Frame Assembly (WCG)

- 2 x Bumpon socket sleeve head screws M3*45 (WC)
- 2 x spring washer M10 (WC)
- 2 x Flat washer M20-OD50 (WCG)



5/11

assemble

Step 7:Attach the Sitting Frame Assembly (WCG) to the Force arms pre-installed on the Main Frame Assembly (WC) using the following method:

- 4 x Bumpon socket sleeve head screws M3*45 (WC)
- 2 x spring washer M10 (WC)
- 4 x Flat washer M20-OD50 (WCG)

6/11

assemble

Step 8: Attach two counterweight rubber pads (WQ8) and two counterweight frame bayes (WCG) to the guide bars (WCH).

Attach the two pre-installed guide bar sets (WCH) to the counterweight frame (WC).

Step 9: Attach the counterweight blocks (WC) onto the guide bar set (WCH) with the indicator hole facing to

Install the guide block set (WCH) onto the guide bar set (WCH).

Attach the counterweight rod (WC) to the counterweight blocks (WC) and guide block (WCH), attach the guide bar retainer plate (WCH) to the guide bar set (WCH).

Attach the guide bar retention plate (WCH) to the counterweight frame (WC) using.

- 2 x M10*45cap washer (WCG)
- 2 x M10flat washer (WC)

Step 10: Attach the 2 Bumpon socket sleeve head screws (WCG) (WCG)

Tighten the bolts with a wrench before proceeding to the next step

7/11

Assemble

Step 11: Thread the wire rope (WCJ) as shown in the picture, the pre-installed sheaves need to be disassembled and reinstalled.

Thread the wire rope (WCJ) through the counterweight with the wire rope (WCJ), and then the rope is installed through the counterweight plug.

Step 12: Connect one end of the wire rope (WCJ) to the main Frame assembly (WC) and the other end to the counterweight frame (WC).



8/11

assemble

Step 13:Slide the two Tube Strips (WCH) into the two Baffles (WQ8) and use the Baffle Fixing Screws (WCH) to attach the Baffles to the Tube Strips.

Slide the Tube Plate (WCH) into the two Baffles (WCH) and use the Baffle Plates to attach to the Counterweight Rack (WC).

Step 14:Attach the Upper Cover (WCH) to the counterweight frame (WC) by.

- 4 x M5*20countsunk socket cheese head screws (WC)

Step 15: Attach the Upper Cover Trim (WCH) to the Counterweight Frame (WC) and snap the Upper Shroud Top Cover (WCH) into the Upper Shroud (WCG) using the following.

- 4 x M5*20countsunk socket cheese head screws (WCG)



9/11

Assemble



Important Notice

Now that the Leg Press/Calf machine is assembled, you need to take a moment to make sure everything is in alignment and plumb. Use a level to check that the guide rods are vertical in both directions. If necessary, adjust the leveling feet on the bottom of the frame backbone to reassemble and tighten the bolts.

10/11

Accessory list

NO	Name and specification	QTY
1	counterweight frame	1
2	lower shield	1
3	Bumpon socket sleeve head screws (WCG11)	2
4	Attachment for stirrups 1	1
5	Main frame assembly	1
6	Bumpon socket sleeve head screws (WCM12)	20
7	spring washer M10	6
8	Flat washer M20-OD50	10
9	counterweight fastener	2
10	Flat s(Qtyse Part main	3
11	Seat Sitting Seat Frame Assembly	1
12	Force Arm Limit Assembly	1
13	Flat washer M10-OD30	4
14	Force arm linkage fixing plate	2
15	Oscillating Force bar assembly	1
16	Pivotal assembly	1
17	Guide bar assembly plate	2
18	Bumpon socket sleeve head screws (WCH2)	4
19	Guide bar	2
20	Guidance block set	1
21	Weight stack	18
22	Counterweight block plate	1
23	Counterweight rubber pads	2
24	Counterweight frame base	1
25	spring washer (WC)	2
26	flat washer (WC)	2
27	cable	1
28	shield	4
29	decorative plate	1
30	decorative strip	2
31	upper shroud	1
32	Upper Shroud Top Cover	1
33	Top cover decoration	1
34	Bumpon socket sleeve head screws(WCH3)	4

11/11