CHEST Installation Guide
Leg Extension / Leg Curl

catalog

Brief introduction ---------- 2
assembly ---------- 3
accessory list ---------- 10

catalogue

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please call our after-sales service immediately for instructions). Please install it correctly. Improper installation may cause injury to the user.

This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

rubber mallet
level ruler
hexagon wrench
Two pouch
spring clamp
Adjustable wrench

assembly

Step 1:Connect the counterweight Chest (2), the seated steel two-strand four-hand connecting frame (2) and the side frame (3) using the following method:

1 X M10*80mm Hexagon socket head screw (4)

4 X M10Spring washer (5)

4 X M10 flat washer (6)

Tighten the bolts with a wrench before proceeding to the next step

Step 2:Attach the counterweight frame (2) to the lower channel (3) using the following method:

1 X M10*80mmHexagon socket chassis head screws (8)

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 3: Attach, first one (8), spring ass (22), and seated steel two-strand flange (20) assembly to the sideboard (3) using the following method:

1 X M10x1mm cap(9-110)

1 X M10*80mmHexagon socket flat countersunk head screws (24)

Tighten the bolts with a wrench before proceeding to the next step

Step 4: Attach the two press stand (12) to the seated hinges strength arm (8) using.

1 X M10x1mm nyon (9-112)

1 X M10*80 Hexagon socket flat countersunk head screws (24)

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 5: Attach the back cushion (26), seat cushion (25) and seat frame (23) with.

1 X M8*20Hexagon socket chassis head screws (28)

1 X M8*80Hexagon socket chassis head screws (28)

4 X M8 flat washer (27)

4 X M8Nylon stop (29)

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 6: Open the chain bar pre-installed on the side frame (3) and thread the seat frame (23) into the chain bar. Then reinstall the chain bar back into the side frame (3).

Step 7: Attach the pedestal reversal cushion (27) to the side frame (3) by.

4 X M8 flat washer (27)

4 X M8Nut washer (30)

Tighten the bolts with a wrench before proceeding to the next step

Step 8: Attach the gas spring (28) to the side frame (3) and seat frame (23).

assembly

Step 9:Attach the seated hinges adjustment frame (28), seated hinges leg pieces frame (29), and side frame (3) using the following method:

1 X M10*80Hexagon socket chassis head screws (4)

4 X M10Spring washer (5)

4 X M10 flat washer (6)

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 10: Place the pre-installed guide bar assembly (30) into the counterweight frame (2).

Install the counterweight block (30) onto the guide bar (30) with the isolation tube facing up.

Install the guide block assembly (30) onto the guide bar (30).

Attach the guide bar assembly (30) to the side frame (3).

Attach the guide bar assembly plate (30) to the counterweight frame (2) to.

1 X M10*80Hexagon socket flat countersunk head screws (24)

Install the counterweight block pin (30) into the counterweight block (30).

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 11: Remove the pre-installed bolts, wrap the wire rope around the pulley as shown below, and reinstall the bolts to secure the wire rope to the pulley.

Take rope to install the wire rope around chassis bar (30) to the seated steel two-strand four-wrap attachment bracket (2).

Step 12: Attach the wire rope (30) to the guide block assembly (30) and the other end is attached to the seated steel 2-hand flange (20).

Tighten the bolts with a wrench before proceeding to the next step

assembly

Step 13: Remove the pre-installed bolts on the Butterfly (30) and use the Butterfly-Plates to attach to the Counterweight Rack (30).

Attach the square shroud (30)(2) to the counterweight frame (30)(2) to.

4 X M4*8Hexagon socket chassis head screws (30)

Finally, snap the square shroud top cover (30)(2) to the square shroud (30)(2).

assembly

Step 14:Place the seatedback trainer in a suitable position and install the corresponding four foot pads (42)(34) for fix.

Important tips

Now that the CHEST is assembled, you need to take a moment to make sure

sure all is level and plumb. Use a level to check that the guide rods are

vertical to both directions. If it is not vertical you must loosen some of

the frame hardware to reassemble and make this so.

Accessory list

NO	NAME	QTY
1	Counterweight Chest	1
2	Connection frame	1
3	side frame	1
4	Hexagon socket chassis head screws M10*80	12
5	spring washer M10	12
6	flat washer M10	12
7	lower shroud	1
8	Hexagon socket chassis head screws M8*80	4
9	Nylon nut	1
10	Frame	1
11	pressure rack	1
12	pressure rod	1
13	plastic cap-78	1
14	Hexagon socket countersunk head screws M10*65	2
15	lower frame	1
16	backrest	1
17	cushion	1
18	Hexagon socket chassis head screws M8*65	10
19	Nylon socket chassis head screws M8*60	3
20	flat washer M8-D16	7
21	Nylon nuts	4
22	backseat rod	1

Accessory list

NO	NAME	QTY
23	backrest	1
24	adjusting frame	1
25	pressure rack	1
26	swing arm	1
27	Guide bar fixing plate	1
28	Guide bar assembly	2
29	Guide block assembly	1
30	counterweight	16
31	counterweight pin	1
32	pedal	1
33	connecting bar	1
34	square shroud	2
35	Butterfly	2
36	Reinforcing plate	1
37	upper shroud	1
38	Hexagon shroud screw plate	4
39	Square Shroud Top Cover	1
40	Flat-filled foot mats	2
41	Counterweight Rack	1
42	Hexagon socket cotton head screws M8*60	2

Note: The installation parts are not listed in this table.