

Table of contents

Introduction ---------- 2
Assembly ---------- 3
Accessories List ---------- 10

Introduction

Please take the time to read this instruction carefully before installation. Please refer to the various lists in the manual to confirm the integrity and quantity of all parts (if there are parts missing or damaged during transportation, please call our after-sales service immediately for instruction). Please install the equipment correctly according to the relevant instructions. This equipment is designed to provide the smoothest and most effective exercise. After installation, you need to understand all functions to use it correctly. If you find any problems during use, you should stop using it immediately to avoid physical injury and equipment damage. Please refer to the relevant instructions in time to inquire about the cause. If you cannot solve it, please call our after-sales service. After reading all the instructions carefully, please continue

Rubber rod
Level
Hexagon wrench
Pen people
Circlip pliers
Adjustable wrench

Assembly

Step 1: Connect the counterweight lower guard (M2) to the counterweight frame (M1) using the following method.
①4 Hexagon socket head screw M2M16 (M6)

Step 2: Connect the base frame assembly (M4) to the counterweight frame (M1) using the following method.
①Hexagon socket head screw M2M45 (M6)
②Spring washer M20 (M20)
③Flat washer M20 (M20)

Step 3: Connect the seat back (seat bracket assembly) (M3), power assist assembly (M8) and bottom frame assembly (M4) as follows:
①Hexagon socket head screw M2M45 (M6)
②Spring washer M20 (M20)
③Flat washer M20 (M20 (M12)

Step 4: Install the Z weight foot (M7) to the weight rack (M1)
Install the Z flat seat foot (M5) to the base assembly (M4)

3/12

Assembly

Step 5: Connect the Seated Calf Slide Assembly (M12) to the Seated Calf Lever Assembly (M11) as follows:
Step 6: Connect the Seated Calf Axis Assembly (M13) to the Base Frame Assembly (M4) as follows:
①Hexagon socket head screw M2M45 (M6)
②Spring washer M20 (M20)
③Flat washer M20 (M20 (M12)



4/12

Assembly

Step 7: Use the gas spring (M09-M09 to connect the pedal bracket assembly (M10 and the power assist assembly (M8).



5/12

Assembly

Step 8: Slide the two rubber weight pads (M20) onto the the guide rods (M12).
Connect the two counterweight frame bases (M15) and the two guide rods (M12) and secure them to the counterweight frame (M1) in the following manner:
①Hexagon socket head screw M2M20 (M6)
②Spring washer M8 (M8)
③Flat washer M8 (M8)
Tighten the bolts with a wrench before proceeding to the next step.

Step 9: Install the 18 counterweights (M22) onto the guide rods (M12) with the concave facing up.
Install the guide block assembly (M22) onto the guide rod (M12).
Slide the counterweight guide (M21) onto the guide rod (M12).
Slide the guide bar retaining plate (M20) onto the guide bar (M12).
Secure the guide bar assembly (M12) to the counterweight frame (M1) as follows:
①Hexagon socket head screw M4x30 (M16)
Tighten the bolts with a wrench before proceeding to the next step.



6/12

Assembly

Step 10: Insert the wire rope (M23) as shown in the figure. Use pre-installed wire ropes to connect the weight rack and pedal assembly.
Note: Each wire rope end must be installed symmetrically with the wire rope (M23)

Step 11: Connect one end of the wire rope (M23) to the seated calf arm assembly (M13), and then connect the other end to the weight rack (M1).

7/12

Assembly

Step 12: Slide the two trim strips (M25) into the two fenders (M26) and attach to the counterweight frame (M1) using the fender hold-down plates.
Step 13: Slide the two trim strips (M25) into the two fenders (M26) and attach to the counterweight frame (M1) using the bolts hold-down plates.
①Hexagon socket head screw M2M16 (counterweight frame (M1) as follows:
②Hexagon socket head screw (M2)

Step 14: Attach the upper lid trim cover (M28) to the counterweight frame (M1) using the following method.
①Hexagon socket head screw (M2)

Step 15: Snap the upper guard cover (M31) onto the upper guard (M30)

8/12

Assembly

Important Tips

Now that the Seated Calf Trainer is assembled, you need to take a moment to inspect the machine and ensure that all bolts are tightened. If any bolts have not been tightened, or if bolts are not plumb, you may have to loosen some of the frame hardware and reassemble and tighten the bolts.

Accessories List

Serial number	Name and specifications	quantity
1	Counterweight rack	1
2	Counterweight lower guard	1
3	Hexagon socket head screw M2M45	4
4	Plastic components	1
5	Footrest bracket assembly	1
6	Power Components	1
7	Weight rack foot pads	2
8	Flat seat foot pad	2
9	Hexagon socket head screw M2M4020	16
10	Spring washer M2010	16
11	Flat washer M20-M300	16
12	Seated calf arm assembly	1
13	Seated Calf Slide Assembly	1
14	Gas spring G400-200	1
15	Guide rod	2
16	Counterweight rubber pad	2
17	Counterweight block	2
18	Hexagon socket head screw M2M420	4
19	Spring washer M8	2
20	Flat washer GB-8102	2
21	Counterweight	16

Accessories List

Serial number	Name and specifications	quantity
22	Guide block set	1
23	Guide rod fixing plate	1
24	Counterweight latch	1
25	Trim Caps	2
26	Boot	4
27	Decorative Strips	2
28	Decorative panels	1
29	Upper guard	1
30	Upper cover decoration	1
31	Lower guard cover	1
32	Hexagon socket head screw M2M420	4

Note: Pre-assembled parts are not listed in this table.